


PROGRAMMING AND OPERATION INSTRUCTION MANUAL

MODEL 713



'RADIODATA' ENCODER
(WITH TCP/IP CONNECTIVITY)



INOVONICS
INCORPORATED

—— USER'S RECORD ——

Model 713 – Serial No. _____

Date Purchased _____

Warranty Card Mailed? — ☐

PROGRAMMING AND OPERATION INSTRUCTION MANUAL

MODEL 713



'RADIODATA' ENCODER
(WITH TCP/IP CONNECTIVITY)

July, 2005



1305 Fair Avenue • Santa Cruz, CA 95060

TEL: (831) 458-0552 • FAX: (831) 458-0554

Visit our Website: www.inovon.com

TABLE OF CONTENTS

Section I - INTRODUCTION

MODEL 713 PRODUCT DESCRIPTION	3
The "Radio Data System" • RDS vs. RBDS • General • Features	
MODEL 713 TECHNICAL SPECIFICATIONS	4
BLOCK DIAGRAM	5

Section II - THE RADIO DATA SYSTEM

RDS: EUROPE vs. AMERICA	6
THE RDS SYSTEM	6
ADDRESSING THE MODEL 713 ENCODER	7
RDS APPLICATIONS SUPPORTED BY THE MODEL 713	7
AF • DI • FFG • M/S • PI • PS • PTY • RT • TA • TP	

Section III - ENCODER INSTALLATION

UNPACKING AND INSPECTION	10
MOUNTING	10
Rack Requirement • Heat Dissipation	
AC (MAINS) POWER	10
Fuseholder • Mains Voltage Selector • Power Cord	
RADIO FREQUENCY INTERFERENCE (RFI)	11
Location • Ground Loops	
SELECTION OF OPERATING MODES	11
Sidechain Mode • Loop-Through Mode	
CONNECTING THE MODEL 713	12
Important Connection Considerations • Sidechain Mode (preferred)	
Loop-Through Mode • Manually Activating the TA Flag	
DATA INTERCONNECTION	14
Computer or Terminal Requirements • Modem Link	
SUBCARRIER INJECTION LEVEL	16
Setting Subcarrier Amplitude • Subcarrier Phase	

Section IV - THE WINDOWS® INTERFACE

PROGRAMMING OPTIONS	18
Advanced Programming for Station Automation	
Simplified Windows® Data-Entry Software	
LOADING AND RUNNING THE SIMPLIFIED WINDOWS® SOFTWARE	18
Installing the Software	

INSTALLING THE USB PORT DRIVER.....	19
SERIAL (COM PORT) ENCODER COMMUNICATIONS	21
THE DATA-ENTRY SCREEN	22
Some notes on Dynamic Messaging • RDS vs. RBDS Mode	
Using ALL-CAPS • PI Code Calculator • Parsing Defined	
“Safe Scrolling” Explained • Sending Data to the Encoder	
Reading Data From the Encoder • File Management	
PROGRAMMING PORT PRIORITIES	28
ENCODER FRONT-PANEL INDICATORS	28
Section V - TCP/IP CONNECTIVITY	
CONFIGURING THE LAN PORT	30
Support Software • Loading DeviceInstaller	
Connecting the Encoder to the Network	
Assigning the IP Address • Confirming Device Properties	
“BROWSER” NETWORK CONNECTION	33
Jave Installation • Java Utility Implications • Password Protection	
USING A ‘VIRTUAL COM PORT’	35
Loading the Redirector Program	
NETWORK CONNECTION FOR AUTOMATION	37
Router Considerations	
Section VI - ADVANCED PROGRAMMINF FOR AUTOMATION	
HARDWARE CONFIGURATION	38
Serial COM Port Configuration	
Network Port Configuration • Power-Up • Echo	
PROGRAMMING SYNTAX	41
How to Type • Using ALL-CAPS • Correcting Mistakes	
Validity Symbols • Firmware Version	
ENCODER HOUSEKEEPING COMMANDS	42
Register Interrogation • Encoder Initialization	
Saving Entries • Encoder Reset • Firmware Version	
STATIC DATA PROGRAMMING	43
PI Calculation • PS • PTY • TP • TA• TA Timeout • AF • DI	
M/S• RT• RadioText Rate • Free Format Group • Saving Entries	
SCROLLING DISPLAYS AND DYNAMIC ENCODER OPERATION	49
Safety Considerations • RadioText • Dynamic PS	
‘Block’ Transmission • “Safe Scrolling”	
Selecting the Dynamic Mode	
Enabling Dynamic PS and Setting the Refresh Rate	
Entering Dynamic PS Text	
Section IV - APPENDIX	
TABULATED LISTING OF ENCODER COMMANDS AND PROMPTS	53
INOVONICS WARRANTY	(INSIDE BACK COVER)

Section I

INTRODUCTION

MODEL 713 PRODUCT DESCRIPTION

The “Radio Data System”	The Radio Data System allows the FM broadcaster to transmit certain digital data along with his regular audio programming. Packets of data transmitted on a low-level subcarrier identify the station and its particular broadcasting ‘format,’ allow for transmission of advertising or other text messages, and perform additional identification, control and housekeeping chores.
RDS vs. RBDS	The Radio Data System was developed in Europe and is abbreviated RDS there. The first US implementation of RDS differed sufficiently from the European standard to warrant its being renamed the Radio <i>Broadcast</i> Data System, or RBDS. Differences between the two standards have been reconciled and minimized over the years, yet RBDS prevails as the US designation. For the sake of clarity and simplicity, the more generic and established term RDS will be used throughout this Manual.
General	Inovonics’ 713 is a complete, ‘full-function’ digital data encoder for implementing RDS at any FM radio station quickly and easily. In addition to static IDs, traffic and other ‘flags,’ The 713 supports dynamic data for sending song titles, advertising messages and specialized in-house applications to the listener’s radio.
Features	<p>Leading features of the Inovonics 713 include:</p> <ul style="list-style-type: none">• Supports the “Scrolling PS” function with automatic ‘parsing’ of messages for proper display on the radio faceplate, or can utilize Inovonics’ unique Safe Scrolling™ mode for reduced distraction to automobile drivers.• Static data are quickly programmed or updated with a PC via USB, serial or LAN interconnects. COM (serial) and LAN (network) interfaces support the dynamic, on-line RDS functions.• Works with popular hard-disk automation systems to transmit song titles, contests, billboards, scrolling advertisements, etc.• Integrates easily with specialized third-party software for increased functionality.• Loop-through or ‘sidechain’ operation with any exciter/stereo generator combination.• Simple to install and easy to use!

MODEL 713 TECHNICAL SPECIFICATIONS

Standards Supported:

European CENELEC and United States NRSC.

RDS Applications Supported:

PI, PS, PTY, TP, TA, RT, AF, DI, M/S, FFG. (A detailed explanation of these applications begins on Page 7.)

Operating Modes:

(1) Loop-Through:

In loop-through operation, the RDS subcarrier is internally mixed with the MPX input and the combined signal is delivered to the RDS OR MPX OUTPUT. The encoder has unity gain in the loop-through mode and accepts a maximum level of 6 volts peak-to-peak corresponding to $\pm 75\text{kHz}$ carrier deviation. Loop-through includes a failsafe Bypass function so that program audio will not be lost if the encoder loses power.

(2) Sidechain:

In sidechain operation, only the RDS subcarrier appears at the RDS OR MPX OUTPUT. This signal is then combined with the FM multiplex baseband in the stereo generator or FM exciter. The monitored MPX (or TTL sync) applied to the PILOT OR MPX INPUT connector is used solely to synchronize the 57kHz RDS subcarrier with the 19kHz stereo pilot.

NOTE: *The 713 is shipped from the factory in the Sidechain mode.*

Pilot or MPX Input:

An unbalanced, bridging BNC input that accepts either the composite/multiplex (MPX) signal or 19kHz TTL-level pilot sync from the stereo generator.

RDS or MPX Output:

An unbalanced, low-impedance BNC output to feed a wideband input of the FM exciter.

RDS Injection Level:

Continuously adjustable between zero and 2 volts peak-to-peak.

USB Port:

Front-panel USB connector for quick computer programming of static data.

Serial Data Port:

RS-232 port (DB-9) for static programming and dynamic messaging. 2400, 4800, 9600, 19200, 39400, 57600 or 115200 baud; 8, N, 1, plain-text ASCII protocol.

LAN Port:

RJ-45 connector; user-programmable DNS for full TCP/IP programmability via Local Area Network or Internet.

TA Switching:

The temporary TA flag is set either by a software command or with a momentary contact closure through a rear-panel connector.

Power Requirements:

105–130VAC or 210–255VAC, 50/60Hz; 10W.

Size and Shipping Weight:

1 $\frac{3}{4}$ "H x 19"W x 7"D (1U); 7 lbs.

BLOCK DIAGRAM

Figure 1, below, is a simplified Block Diagram of the Model 713. Because of the all-digital, minimalist-discrete-component nature of encoder circuitry, we have not provided schematic diagrams of the Model 713 in this Manual. As they say on the back of TV sets:

NO USER-SERVICEABLE COMPONENTS
INSIDE. REFER ALL SERVICING TO
QUALIFIED TECHNICAL PERSONNEL.

Inovonics does, of course, fully support the Model 713, and will provide detailed service information upon request, including sources for the few replaceable parts and factory-direct replacements for firm-ware-proprietary integrated circuits.




Figure 1 - Block Diagram, Model 713 RDS Encoder

Section II

THE RADIO DATA SYSTEM

RDS: EUROPE vs. AMERICA

The European Broadcasting Union (EBU) and its member countries originated the concept of “Radio Data” transmission. The European RDS specification, CENELEC Standard EN50067, was first published in 1984. It was revised in 1986, 1990, 1991 and 1992.

European RDS has grown in use following initial adoption of the Standard. RDS is nearly universal throughout Europe; it is almost impossible to find a European FM broadcasting station that does *not* carry a radio data subcarrier.

The popularity of RDS in Europe is very much in contrast with initial reluctance on the part of US broadcasters to embrace this technology. This can be ascribed to material differences in broadcasting practices.

Almost without exception, FM broadcasting in the United States is ‘detached’ and independent; that is, each station originates its own programming. One exception might be America’s National Public Radio, though for most of the broadcast day even NPR stations originate, or at least schedule, their own programs.

Much of European broadcasting is similar to the concept of network radio that was common in the US prior to the 1950s. In Europe, a central program originator may have many transmitting facilities of modest power situated throughout the country, at several different frequencies to blanket a designated service area. The European disposition toward lower-power transmitters can be found on the “local radio” level as well.

The European concept of a *service area* equates to the US broadcaster’s *market*. The subtle difference between these designations further characterizes broadcasting practices and ethics. RDS benefits the European broadcaster through almost an altruistic endeavor to be of *service* to his listeners. The US broadcaster is *marketing* his programming, and is primarily interested in how he can create additional revenue from RDS.

THE RDS SYSTEM

RDS is a digital data channel transmitted as a low-level subcarrier above the range of the composite stereo program signal in the FM baseband. The data transmission (baud) rate is comparatively low,

yet it is quite robust because of data redundancy and effective error correction.

It is not within the scope of this Manual to cover the details of RDS subcarrier coding and modulation. For this the reader is directed to the Specification appropriate to his location, either the CENELEC EN50067 Specification for Europe, or the United States NRSC Specification. It is assumed that the user has some familiarity with the concept of RDS, since the balance of this Manual will deal with specific implication of RDS implemented with the Inovonics Model 713.

ADDRESSING THE MODEL 713 ENCODER

Many applications, such as Radio Paging, navigational assistance, roadside message billboards, song titles, stock market updates, etc. all require continuous, on-line access to the RDS encoder by one or more service providers. Some of these applications may promise additional revenue to the station. The Model 713 offers these capabilities and may be addressed by simple ASCII commands, either from station automation, via a network, or directly by a connected computer.

Particularly in Europe, RDS encoders may be linked with one another for network support applications. The UECP, or Universal Encoder Communication Protocol was developed by CENELEC to support this form of operation, but over the years has seen decreased usage in favor of TCP/IP addressability or direct connection with station automation. Thus the 713 does *not* support the UECP.

RDS APPLICATIONS SUPPORTED BY THE MODEL 713

The following is an alphabetical listing of RDS applications that are fully supported by the Model 713. The standardized RDS application abbreviation is followed by an expansion of the application name and a short explanation of the function.

- AF List of Alternative Frequencies:** A network broadcaster, or one with low-power rebroadcast transmitters (translators) to fill holes in his coverage area, can include a list of all frequencies where the identical program can be heard simultaneously. The RDS receiver (particularly the upscale car radio) constantly searches for the best signal that carries the very same program. When a better signal is found, the radio re-tunes with no noticeable interruption. The principal utility of this RDS function is with European radio networks and US stations with 'translators.'
- DI Decoder Information:** This is one of several 'flags' that convey yes/no or other very basic data. This particular flag tells the receiver whether the broadcast is monaural, or is being transmitted in any of several methods of stereo or binaural broadcasting. As

many as 16 encoding options may be accommodated! This is a rather esoteric function and, thus far, remains unused both in Europe and in the US.

FFG **Free Format Groups:** A provision has been included in the Model 713 to transmit proprietary data directly within a legitimate RDS group. This is a special use of the encoder for non-standard applications. Additional notes can be found on Page 49.

M/S **Music / Speech Switch:** This flag simply indicates whether music or speech is the primary broadcast programming. The purpose of this function is not well explained in the respective Standards; hence it comes as no surprise that it is not widely used.

PI **Program Identification:** This block of data identifies the broadcast station with a hexadecimal numerical code, which becomes the “digital signature” of the station. The code is assigned by the broadcasting authority in most countries, but in the US it is calculated from a numerical encoding of station call letters. The receiver processes the PI code to assist automatic tuning features (station memories), and to prevent false switching to alternative frequencies that might be shared by broadcasters in nearby regions.

PS **Program Service Name:** This is the station’s “street name” that will appear on the receiver faceplate display. The PS can be up to eight characters in length (including spaces) and can be as simple as the station’s call letters: *KWOL* or *KWOL FM*, or a slogan: *NEWTALK* or *LIVE 95*. The Program Service Name is automatically displayed, even on automobile receivers, and because of driving safety considerations broadcasters are generally discouraged from scrolling messages in this field. As a matter of fact, it is a violation of both the CENELEC and the NRSC standards to scroll the PS display, although the practice has become universally common.

PTY **Program Type:** The PTY data flag identifies the station format from a collection of pre-defined categories. Many RDS receivers are able to seek the listener’s preferred format automatically. This means that a car radio can switch from a fading station to a stronger one that carries the same *variety* of music, though not the very same program, as provided by AF switching. The PTY function of RDS helps a broadcaster catch ‘transient audience’ share. A listing of the PTY categories is given on Page 44.

Under some programming circumstances, the PTY identifier may be made ‘dynamic,’ changing between categories for a station that “dayparts” (changes its format for specific time periods). The PTY code is not meant to change from song to song or to accommodate a top-of-the-hour newscast, however.

RT **RadioText:** This is a 64-character block of plain text that the listener can select for visual display on the faceplate of the radio by pressing an INFO button on the receiver. This function is not available on many automobile radios for safety reasons, which has

precipitated the frowned-upon practice of scrolling the PS field instead.

Most radios have limited alphanumeric display capability, so the 64 characters of RadioText march across the front panel, much akin those annoying LED advertising signs found in airport buses or fast food emporia. Like the scrolling-PS implementation, RadioText can announce song titles and performers, run special promotions or contests, or broadcast sponsors' messages.

- TA Traffic Announcement:** This is a *temporary* flag added to the RDS data stream *only* as a traffic bulletin is being aired. Some RDS car radios can be set to search for traffic bulletins among various TP stations (see **TP** below) while tuned to a listener's preferred program, or even while playing a tape or CD. As soon as any TP station broadcasts a traffic bulletin, the receiver *temporarily* switches-over to receive it. When the bulletin is finished, the receiver switches back to the original program, tape or CD.
- TP Traffic Program Identification:** The TP flag identifies the station as one that routinely broadcasts traffic bulletins for motorists as part of its normal, everyday programming. When the TP flag is displayed on the receiver faceplate, the radio is searching for traffic announcements. The radio keeps track of TP stations offering this service to speed up the search-and-switch process.

Section III

ENCODER INSTALLATION AND SETUP

UNPACKING AND INSPECTION

As soon as the equipment is received, inspect carefully for any shipping damage. If damage is suspected, notify the carrier at once, and then contact Inovonics.

We recommend that you retain the original shipping carton and packing materials, just in case return or reshipment becomes necessary. In the event of return for Warranty repair, shipping damage sustained as a result of improper packing for return *may invalidate the Warranty!*

IT IS VERY IMPORTANT that the Warranty Registration Card found at the front of this Manual be completed and returned. Not only does this assure coverage of the equipment under terms of the Warranty and provide a means of tracing lost or stolen gear, but the user will be sent specific SERVICE OR MODIFICATION INSTRUCTIONS issued by Inovonics.

MOUNTING

Rack Requirement The Model 713 mounts in a standard 19-inch equipment rack and requires only 1¾ inches (1U) of vertical rack space. The use of plastic washers is recommended to protect the painted finish around the mounting holes.

Heat Dissipation Consuming less power than the light in a refrigerator, the 713 itself generates negligible heat. The unit is specified for operation within an ambient temperature range extending from freezing to 120°F/50°C. But because adjacent, less efficient equipment may radiate substantial heat, be sure that the equipment rack is adequately ventilated to keep its internal temperature below the specified maximum ambient.

AC (MAINS) POWER

Fuseholder The fuseholder is at the far left of the front panel. Apply downward pressure and pull the cap outward to access the 5mm mains fuse. Note that the cap has space for a spare fuse as well. The cap is re-seated by reversing the removal process. This fuse also serves as a

front-panel emergency power disconnect for the Model 713 in lieu of a front-panel power switch.

**Mains Voltage
Selector**

Unless specifically ordered for export shipment, the Model 713 is set at the factory for operation from 115V, 50/60Hz AC mains. This can be confirmed by checking the designation next to the mains connector on the rear panel. The *inappropriate* voltage and fuse value will have been crossed out at the factory with an indelible felt marker.

To change the mains voltage, first remove the top cover of the unit. A clearly marked slide switch is next to the AC mains connector on the encoder circuit board. *With power disconnected*, use a small screwdriver to set the switch for 115VAC or 230VAC operation.

Be sure to install the appropriate fuse listed on the rear panel. You can remove the factory strikethrough with (a probably carcinogenic!) solvent, and then cross out the inappropriate marking with an indelible felt pen.

Power Cord

The detachable IEC-type power cord supplied with the encoder is fitted with a North-American-standard male plug. The individual cord conductors may be color-coded in either of two ways:

1) In accordance with US standards:

BLACK = AC "HOT" WHITE = AC NEUTRAL
GREEN = EARTH GROUND

2) To European CEE standards:

BROWN = AC "HOT" BLUE = AC NEUTRAL
GRN/YEL = EARTH GROUND

RADIO FREQUENCY INTERFERENCE (R F I)

Location

Although it is natural for the 713 to be installed alongside high-power transmitters, please practice reasonable care and common sense in locating the unit away from *abnormally* high RF fields.

Ground Loops

Because the unbalanced PILOT OR MPX INPUT and the RDS OR MPX OUTPUT of the Model 713 are chassis-ground-referenced, a mains frequency or RF ground loop could be formed between the input or output cable shield grounds and the AC power cord ground. A 'ground-lifting' AC adapter may well remedy such a situation, although the chassis somehow must be returned to earth ground for safety. Generally, being screwed-down in the equipment rack will satisfy the safety requirement.

SELECTION OF OPERATING MODES

Sidechain Mode

Configured for sidechain operation, the rear-panel PILOT OR MPX INPUT connector simply bridges (monitors) the output of the stereo generator to derive timing information from the 19kHz stereo pilot. Alternatively, a TTL-level 19kHz sync squarewave may be applied

to this input. We do not recommend this, however, as the phase relationship between the synchronizing squarewave and the 19kHz pilot component in the composite, multiplex output of the stereo generator may not be assured.

In sidechain operation the RDS OR MPX OUTPUT will contain *only* the RDS subcarrier, the composite/MPX signal is *not* routed through the 713. This operating mode best preserves multiplex signal integrity and assures uninterrupted program transmission in the event of a catastrophic encoder failure (very doubtful). As delivered, the 713 is configured for sidechain operation.

Referring to the jumper installation drawing, Figure 2, below, locate the 3-terminal jumper strip, located about an inch (2.54 cm) to the rear of the two BNC connectors on the Model 713 circuit board. The shorting clip is positioned “down” for sidechain operation, as shown in Figure 2.

Loop-Through Mode

When the Model 713 is jumpered for loop-through operation, the RDS subcarrier is internally combined with the composite/MPX signal. This means that the RDS OR MPX OUTPUT *will include* the composite/MPX program signal (at unity gain) with the RDS subcarrier added. Also, in the loop-through mode the internal bypass relay will pass-through the multiplex signal in the event of an encoder power failure. Figure 2, below, shows the “up” position of the shorting clip for loop-through operation.




Figure 2 - Encoder Mode Jumpering

CONNECTING THE MODEL 713

Important Connection Considerations!

The 713 encoder must be properly configured for the desired operating mode: *sidechain* or *loop-through* before it is installed in the signal path. See the preceding instructions to confirm that the encoder circuit board is properly jumpered before connecting the Model 713 to other air-chain equipment.

Also, it is important that the operating software be installed on the PC *before* it is connected to the encoder for programming the ‘static’ message registers and operating defaults. In addition, we heartily recommend testing the encoder with its controlling interface (com-

Sidechain Mode (preferred)

puter, terminal, automation, etc.) *before* it is placed in the air chain. This will ensure that 2-way communication with the encoder can be established and that the encoder is properly initialized.

Attach a BNC ‘T’ adapter to the composite/MPX output of the stereo generator as shown in Figure 3, below. Connect one side of the ‘T’ directly to a wideband (composite/ MPX) input of the FM exciter and the other side to the PILOT OR MPX INPUT of the Model 713. (This is only a bridging ‘sync’ connection when the circuit board has been jumpered for sidechain operation and does not load or otherwise affect the composite/MPX signal.)

If the stereo generator has a dedicated 19kHz TTL-level output designated for RDS encoder sync, you *may* connect this to the encoder PILOT OR MPX INPUT. We do *not* recommend this, as a dedicated 19kHz sync output may not have the proper phase relationship with the stereo pilot.

Cable the RDS OR MPX OUTPUT of the encoder to a second wideband (subcarrier) input of the FM exciter.




Figure 3 – ‘Sidechain’ Encoder Connection

Loop-Through Mode

In the loop-through mode, the output of the stereo generator is cabled directly to the PILOT OR MPX INPUT of the Model 713 as shown in Figure 4 on the next page. Connect the RDS OR MPX OUTPUT of the encoder to a composite/MPX wideband input of the FM exciter. When internally jumpered for loop-through operation, the composite/MPX signal *passes through* the encoder with unity gain, and with the RDS subcarrier added.




Figure 4 - Loop-Through Encoder Connection

Manually Activating the TA Flag

The Travel Announcement feature is a temporary command. This flag *must* coincide with the actual voice warning of a traffic condition. The encoder includes a provision to access this flag with a manual switch closure, which will doubtless prove faster, more convenient and more reliable than software control of the TA function.

A run of twisted-pair cable may be taken from the LOCAL TA CONTROL barrier strip connector on the rear panel of the encoder to a normally open *momentary* (spring-return) pushbutton switch located conveniently at the announcer's operating position.

The TA flag will be transmitted as long as the switch is held down. *It is important that this alert is active only for the duration of a traffic announcement.* The TA flag must be turned off immediately after completing the verbal traffic warning.

DATA INTERCONNECTION

The Model 713 encoder may be addressed three ways: 1) a front-panel USB port, convenient for setting service flags and entering static RDS data; 2) a rear-panel RS-232 COM PORT, which may be connected directly to station automation equipment for dynamic messaging... song titles, weather info, etc.; and 3) a rear-panel TCP/IP LAN PORT that gives the 713 addressability via Local Area Network or the Internet. Front-panel LEDs indicate the active port.

NOTE: For USB or RS-232 serial interface with a PC for local programming of the 'static' data registers, software must be installed on the computer *before* it is connected to the encoder. Refer to software installation instructions beginning on Page 18.

For direct connection to station automation, the rear-panel RS232 COM PORT DB-9 connector is addressed in simple ASCII text. Communication syntax is explained with advanced programming instructions in Section VI.

Computer or Terminal Requirements

For fast and easy encoder programming via the serial COM port, Windows®-based RDS Data-Entry Software routines have been supplied on a CD-ROM. This software also may be downloaded from the Inovonics Website. Alternatively, the encoder may be addressed with any computer running a ‘terminal emulation’ program (e.g.: *HyperTerminal*, normally supplied with *Microsoft Windows*®), or with a simple “dumb” terminal that has an RS-232 interface. The encoder can accommodate several baud rates, but the factory default is 9600 baud. Set the terminal (or terminal program) for: 9600-baud / 8 data bits / no parity / one stop bit (9600,8,N,1).

Static PS and other IDs, flags, the alternative frequency list and operating mode options are uploaded into non-volatile encoder memory from a PC, either with USB, RS-232 serial or TCP/IP connections. If scrolling-PS or *dynamic* RadioText messaging is *not* used, a slogan, phone number or advertising messages can also be entered manually into the 64-character Dynamic PS and RadioText fields. These will be displayed on the radio faceplate as a repetitive scrolling-PS or static RadioText messages. Keep in mind that Dynamic Radio Text and scrolling-PS are separate functions, both of which are simultaneously available with the Model 713.

Once static data has been uploaded, the encoder may be disconnected from the computer, relocated to another operating point, or reconnected to an alternative data source for dynamic messaging. This may be a hard-disk-based station automation system that provides song title and artist, plus ads or station promos. The automation system must be configured to the encoder’s baud rate and programmed to deliver dynamic data in proper syntax as explained by the advanced instructions in Section VI.

Modem Link

In addition to the LAN connection, a modem link also may be used for addressing the encoder from a remote location via RS-232 serial connection. When properly configured, a modem link will appear ‘transparent,’ as if the encoder were connected directly to the controlling system. Figure 5, below, shows proper pin connections for the cable used to connect the Model 713 to a conventional external modem. The three conductors shown are the only ones required.




Figure 5 – Encoder/Modem Connections

SUBCARRIER INJECTION LEVEL

The front-panel INJECTION LEVEL ADJUST potentiometer sets the amplitude of the RDS subcarrier. This is a 15-turn potentiometer to give the required adjustment resolution.

In the *sidechain* mode of operation, the RDS subcarrier is the only signal that appears at the rear-panel RDS OR MPX OUTPUT connector. Because some exciters require a high signal level at auxiliary wideband (SCA) inputs, the RDS signal has been made adjustable to any value between zero and 2 volts, peak-to-peak.

In *loop-through* operation of the encoder, the composite/MPX program signal that is fed to the PILOT OR MPX INPUT appears with unity gain at the RDS OR MPX OUTPUT. A typical peak-to-peak level of the Composite/MPX program signal is 3 volts. The same 0-2V RDS subcarrier level range is available in this mode, so obviously the INJECTION LEVEL ADJUST control will be closer to the counterclockwise end of its travel to give a level of 0.1 volts p-p, which would correspond to the typical 3% to 4% RDS injection.

Setting Subcarrier Amplitude

Injection is best set with a modulation monitor that includes a subcarrier measurement utility. Alternatively, a basic mod-monitor can be used alone, but program modulation and the stereo pilot must be turned off to resolve the low RDS injection level.

NOTE: If using a mod-monitor that does *not* have separate subcarrier measurement ability, keep in mind that mod-monitors are *peak-responding* for total-mod readings near 100% modulation, but may be *average-responding* for measurements at low modulation levels. Because the RDS subcarrier is a complex, suppressed-carrier double-sideband signal, an average reading of 3% RDS injection can represent a level that is substantially higher when measured peak-to-peak. It is the *peak* level we are interested in with broadcasting.

Perhaps a better means of setting injection when a subcarrier monitor is not available is simply to bridge the input of the exciter with an oscilloscope using a BNC “T” adapter. With the audio program muted, the peak-to-peak value of the 19kHz stereo pilot signal can be noted. With this figure in mind, turn off pilot modulation (but do not *disconnect* the stereo generator) and set the peak-to-peak value of the RDS subcarrier to about one-third of the measured 19kHz pilot level. When programming is restored, the mod-monitor should indicate a 3% increase in total modulation, though this may be difficult to resolve near the 100% mark. Readjust the output level of the stereo generator to fine-tune the original total-mod figure.

In the United States, the FCC permits an extra 5% modulation for each subcarrier, with total modulation not to exceed 110% even with two or more subcarriers.

Subcarrier Phase

In the interest of maintaining optimum carrier modulation by the program signal, the 57kHz RDS subcarrier should be in *quadrature* with the 19kHz stereo pilot. Both in-phase and quadrature relationships are shown here in Figures 6 and 7, respectively. Note that

a quadrature relationship (Figure 7) yields a slightly lower peak level, which allows the greatest carrier modulation by the program audio signal.




Figure 6 – Subcarrier In-Phase




Figure 7 – Subcarrier in Quadrature

The Model 713 is skillfully and carefully aligned at the factory to ensure that the subcarrier is in quadrature with the stereo pilot, whether the encoder is used in the sidechain or in the loop-through operating mode. Although some stereo generators supply a pilot-sync reference for RDS (usually a TTL-level squarewave), this reference may or may not be in exact phase with the actual stereo pilot component of the composite/MPX signal. For this reason we recommend using the composite/MPX signal for synchronization. In the sidechain mode, the Model 713 simply bridges the output of the stereo generator and does not load or otherwise compromise the composite/MPX signal.

Section IV

THE WINDOWS® INTERFACE

PROGRAMMING OPTIONS

Advanced Programming for Station Automation

Developed as a fully ‘interactive’ RDS encoder, the 713 can interconnect directly with station automation to transmit dynamic messaging to the receiver. Examples of this are song title and artist information, weather reports or air personality ID. Station automation communicates with the Model 713 either through an RS-232 serial data interface or a LAN network port.

The data stream from a station automation system must be formatted properly for communication with the 713 encoder. Commands require proper preambles, or headers, so that the 713 interprets dynamic data as valid command sets. This is covered in Section VI.

Simplified Windows® Data-Entry Software

To help get RDS on-air quickly and painlessly, a very simple and intuitive Windows® interface has been included on the CD-ROM that comes with the Model 713 encoder. This can be used by anyone to set the static IDs and flags, to program default entries into the dynamic messaging fields, and to set other operating parameters that affect how data from station automation is displayed on the radio faceplate.

LOADING AND RUNNING THE SIMPLIFIED WINDOWS® SOFTWARE

NOTE: To avoid hardware conflicts and encoder connection problems, install the software before attempting to connect the encoder with the computer.

Installing the Software

Insert the supplied CD. The software has an ‘autorun’ utility to automatically begin the installation routine. However, in the event that the Setup Wizard does not automatically start, use Windows Explorer to navigate to the CD Drive (D:). Right-click the drive and select Explore to find the file: setup.exe. Double-click this file to launch the Wizard (shown here) that will guide you through the several installation steps.



Unless you have a specific reason to make changes, simply accept the default recommendations and click Next> at each step, but with these exceptions:

- 1) When prompted to place an icon on the computer Desktop, check the box to do so.
- 2) At the final step, elect NOT to launch the program.
- 3) Close the software installation utility.

Next, follow the procedure below to install the USB driver. If the front-panel USB port is NOT to be used, skip this procedure and follow instructions for RS-232 serial COM port interface.

INSTALLING THE USB PORT DRIVER

Once the programming software has been installed on the computer, a special USB port driver must also be installed if that particular computer is ever to address the encoder through the front-panel USB port. The station's 'utility laptop' or other machine used for quick, local encoder programming must have both the programming software and the USB driver installed.

When the programming software was installed, the USB driver was put into a folder within the Model 713 program file. With a normal installation (as described above) under Windows® XP, the driver will have been located here: My Computer / Local Disk (C:) / Program Files / Inovonics Inc / Inovonics 713 RDS encoder / Drivers. Use the following steps to install this driver.


1. With the Model 713 Encoder powered-up, connect the front-panel USB port to the computer using the cable supplied. This should immediately bring up a New Hardware notification above the computer Taskbar and start the Found New Hardware Wizard. As the driver is already on the computer hard drive, click the No, not this time bubble, and then: Next>.



2. This next screen verifies the location of the driver, which should appear automatically in the box as shown. Click: Next>.



3. Windows® will advise that this driver is 'unsigned.' Trust us and click Continue Anyway.




4. The driver will be installed, and a notification that the hardware is ready to use will appear above the Taskbar.



The software installation will have placed an icon on your computer Desktop. Double-click the icon to start the data-entry software.

Before data can be uploaded to the encoder, software must be set for the proper communications mode.



If you will continue using USB connectivity at this time, click on Device at the top of the data-entry screen. This will bring up the Settings box shown above. As a USB connection has already been es-

tablished, the USB Devices bubble should be checked, and the actual serial number of this encoder's USB port will be listed as shown in the illustration.


NOTE: The *port* serial number shown is NOT the same as the primary, *back-panel* serial number of the Model 713 Encoder. Each encoder is assigned a port ID so that multiple encoders can be addressed from a common USB hub if required.

To confirm the equipment selection, highlight the connected device (Device 1 in our illustration) and click OK. This will clear the Settings box and make the data-entry screen available.

SERIAL (COM PORT) ENCODER COMMUNICATIONS

The serial connection may be either a direct 'serial extension' cable, or it may utilize any *bidirectional* RS-232 link, such as a dial-up modem or a 2-way serial data link of the STL. These should be configured to appear 'transparent' to the programming process.

Software communications selection is called-up from the data-entry screen under: Device / COM Port devices. Clicking the bubble and setting serial port parameters, as shown below, enables encoder programming through the COM port.



The Model 713 can accommodate serial port baud rates between 2400 baud and 115200 baud. 9600-baud is the factory-default COM port rate. Because the volume of data sent is relatively small, a faster speed will not materially improve COM-port response time. However, a different rate may be used if, for instance, an RS-232 link associated with an STL is restricted to a lower baud rate. The encoder baud rate may be set through either the COM or the USB ports.

NOTE: When setting serial data SPEED on the data-entry screen, the selection will hard-set the *encoder's* COM port speed with the

next Send to Encoder command. The supplied Windows® data-entry software automatically detects COM port speed and self-adjusts. This can be confirmed under Device / Settings, as shown on the previous page. But when the encoder is addressed by station automation that has a *hardware* baud-rate setting, communications will fail if the rates do not match. In this event, use the supplied Windows® software and a direct computer connection (via either the COM or the USB port) to hard-set the encoder baud rate to the fixed rate of the programming source.

The software installation will have placed an icon on your computer Desktop. Double-click the icon to start the data-entry software.

THE DATA-ENTRY SCREEN


Some Notes on Dynamic Messaging

Dynamic messaging can take either the ‘approved’ form of a Radio-Text message, which can be seen on the faceplate of only those radios equipped with an INFO or DATA button, or it can be presented in the PS field through a technique that has come to be known as “scrolling-PS.” This latter option is “forbidden” by the European CENELEC and United States NRSC standards committees, as it presents a distraction to automobile drivers. Nevertheless, both forms of dynamic messaging are in widespread use in the US and abroad.

In addition to dynamic messaging, there is a certain amount of obligatory, repetitive *static* information that is broadcast continuously over the RDS data stream. These are IDs and ‘flags’ that tell the receiver ‘who is sending what, and how.’ For all practical purposes, this information is fixed, and may be programmed (by local computer connection) into the non-volatile memory of the Model 713 before it is connected to station automation for dynamic messaging.

RDS vs. RBDS Mode

Select the proper encoder operating mode before entering data. For North America (US, Canada and Mexico), the button indicated by the arrow here should be toggled to read: RBDS. For the rest of the world, it should be set to: RDS. This is important, both for setting the PI code and to make sure that the proper PTY group is selected.



Using ALL-CAPS


Because many RDS radios cannot display a full set of ASCII characters, use of mixed (capitals and lowercase) letters can result in a very bizarre or completely unreadable message. Thus this Windows® data-entry software forces the use of all-capital letters. This same practice should be observed when the encoder is addressed by station automation.

PI Code Calculator

The PI code is your station’s ‘digital address.’ It is a hexadecimal code that is assigned by an appropriate broadcasting authority in most countries, but in the United States the PI code is numerically calculated from the station’s callsign. We have provided a calculator


utility within the Model 713 software screen. This calculator is active only in the RBDS operating mode. An in-depth discussion of the mathematical calculation is given on Page 43.

To use the PI calculator for US ‘K’ and ‘W’ callsigns, simply enter call letters into the Call box and click the left-facing arrow. The hexadecimal code will automatically be entered in the Code box. If the hexadecimal code for a US station is known, you may enter it under Code, and then click the right-facing arrow to confirm a proper call letter match.



In all other countries the appropriate broadcasting authority is responsible for assigning the station’s PI codes, which is then entered directly into the Code box. Canadian and Mexican codes should *never* bring up US-look-alike call letters when challenged by clicking the right-facing arrow! When in doubt: 1) consult the broadcasting authority, 2) check the latest published RDS Specification, or 3) log onto the primary RDS information website: www.rds.org.uk for help.

The illustration below shows the data entry screen filled-in for a typical US rock station. Each of the entries will be explained individually, with references to other pages that further detail the discussed RDS function.



- PI As already explained, software automatically calculates the PI Code for US stations; otherwise the hexadecimal PI code must be entered manually in the (Code) PI field. PI coding is discussed on Page 8.
- PTY Program Type identifies the station’s programming format from a list. There are two lists, one for the European RDS system and one for the American RBDS specification, hence the button that toggles between RBDS and RDS. With the proper geographical setting,

choose the station format from the drop-down list. Refer to Page 8 for more information on PTY lists and their differences.

PS The 8-character PS field is for the “street name” of the station. This will appear on the radio faceplate whenever a dynamic, scrolling-PS message is *not* being transmitted. PS is discussed on Page 8.

PARSE The Model 713 encoder includes a built-in utility to ‘parse’ messages automatically when dynamic messaging is enabled (see DPSS). Parsing refers to the breaking-down of messages into meaningful segments for efficient display on the 8-character alphanumeric read-out common to all RDS receivers.

Parsing Defined Parsing is used in the “block” mode of message transmission, the more popular ‘grouped-word’ method. Once parsing options are set, this encoder function is valid for any scrolling-PS message, whether it is entered into the static DPS register, or received as ASCII text from station automation.

Very short words are sent together in groups. For instance, *THIS IS* constitutes seven characters that can be sent as a group. The same would hold true for *OF THE* or *NOW HERE*. Longer words, up to and including 8 characters, are sent individually: *WARNING* or *DOUGHNUT* or *BICYCLE*. The Model 713 can either center words that are sent individually on the radio display or left-justify them. This will be covered along with the function of the PARSE button.

Words that exceed the available 8 characters are ‘sidestepped’ through two or more consecutive displays. Examples: *EMERGENC* followed by *MERGENCY*, or *SUPERMAR* followed by *UPERMARK* and *PERMARKE* and *ERMARKET*. This method of splitting words gives a good sense of continuity and readability.

“Safe Scrolling” Explained Clicking on the PARSE button will show a drop-down menu of the numbers 0 through 9. With 0 or 9 selected, parsing action will be just as described. 0 centers word groups, 9 left-justifies them. Other choices are variations of what we call our “Safe Scrolling” message display mode and will be mentioned later.

We developed Safe Scrolling because of our concern over distracted car drivers. Viewing a message in the block mode (complete words or groups of words), a driver must pay close attention to the radio display, or risk missing part of the message. Although the message may be repeated over and over, the driver may tune in at the end of a song, and in finding out who sang the number could rear-end the car in front.

Safe Scrolling ‘marches’ the message across the display screen one character at a time, not unlike soldiers passing a reviewing stand. The message requires a much longer transmission time in this mode, but a glance at the radio display every ten to fifteen seconds still allows the driver to get the full message without missing words.

Setting PARSE to 1 will scroll the message one character at a time, as described. Other numbers also safe-scroll the message, but at 2, 3, 4, and up to 8 characters at a time. Selecting 9 will parse, as described, but text will be left-justified rather than centered on the dis-

play. 2 through 8 may be useful in some special RDS applications, but 0 and 1 are the primary PARSE selections. To recap: 0 will enable the more-popular, centered-auto-parsed block mode and 1 the Safe Scrolling, letter-by-letter option.

DPSS The speed of dynamic PS messaging is set here, or dynamic PS messaging can be turned off entirely. When OFF is selected, the dynamic PS message remains in the non-volatile encoder memory, but only the 8-character default static “street name” typed into the PS field will be displayed on the receiver faceplate.

Setting the speed at 1 will result in the slowest refresh rate of the ‘block’ message, or slowest Safe Scrolling. 9 is the fastest speed, but many RDS radios display gibberish at high speed settings. The display *should* be stable with any radio at a speed setting of 7 or lower.

DRTS RadioText is the separate 64-character message that may be displayed on some radios when the listener pushes an INFO or TEXT button. Many automobile receivers will not allow RadioText display, hence the popularity of dynamic, scrolling-PS despite rules and cautions against its use. RadioText is sent as a single, 64-character message, so it generally needs to be refreshed less frequently in the normal RDS transmission cycle.

DRTS sets this RadioText transmission refresh rate. As a *static* RadioText message is not generally called upon to convey dynamic advertising or song-title information like the scrolling-PS function, a setting of 3 should be adequate. Higher settings may interact with other functions and compromise the stability of any scrolling-PS messages.

When DRTS is set to OFF, the RadioText message will not be transmitted. It will remain in the software and encoder memory, however.

MS Select MUSIC or SPEECH as the primary station format (see Page 8).

TA The TA flag is to be sent only for critical traffic-related announcements, and then only while the announcement is being broadcast. We fervently recommend using only direct-connected, hardware-switch-activation of the TA flag, as described on Page 14.

However, as the 713 encoder may be some distance from the studio, and addressed by TCP/IP, serial (or modem) connection, provision has been made to set the TA flag with a software command. Selecting ON from the drop-down TA menu will set the flag, which will remain on until reset by selecting and sending OFF., or until the TA function times-out, if timeout has been programmed (see Page 46).

TP Set this to YES only if your station broadcasts traffic advisories and will activate the TA flag for critical announcements. This is clarified on Page 9.

DI This is generally set for STEREO, unless the station has all-monaural programming and does *not* transmit the stereo pilot signal. DI is discussed in further depth on Page 7.

DPS Up to 64 characters of information may be entered in the Dynamic PS messaging field. This can be set either to ‘parse’ (see Page 24), or to scroll, one character at a time. Both the European CENELEC and the American NRSC specifications for RDS/RBDS operation expressly forbid ‘Dynamic PS’. Nonetheless, dynamic messaging is flaunted in the face of these august agencies and is currently practiced worldwide.

The tic marks above the DPS entry field are useful in manually formatting dynamic, scrolling-PS messages that are not automatically parsed; that is, broken into sensible groups by Model 713 software. The following illustration shows how one can manually format a scrolling PS message for optimum readability. This same illustration may prove valuable when it comes to deciding how to format non-parsed messages within station automation software.

NOTE: In this illustration, the menu that drops-down from the PARSE button would be set to 8, meaning that the full eight characters available on the radio faceplate would be sent as a group at each transmission interval. Again, the automatic parsing function of the Model 713 Encoder is *not* called into play for this illustration.

When simply *scrolled*, one character at a time (PARSE = 1), the message shown in the example here could be read easily, although it would take about a minute for all characters to march sequentially across the receiver faceplate. Alternatively, automatic parsing (PARSE = 0) would break the message into independently-meaningful groups with much faster message throughput.

But as it is typed in the example on Page 23, and with PARSE set to 8 (corresponding to the limit of the receiver display), the message would show up something like this:

L	I	S	T	E	N	T		O	B	R	E	T	A		N	O	C	H	E	T	
I	N		T	H	E		M	O	R	N	I	N	G	-		T	H	E	Y	A	R
E		H	I	L	L	A	R	I	O	U	S										

By altering the text slightly and forcing the message to break into standalone clusters of eight characters, ‘block’ transmission of essentially the same message would be far more readable. Here is an example of how the message could be formatted:

Each sequentially-displayed 8-character ‘screen’ would break at the major tic marks and show up on the radio faceplate as shown below.

L	I	S	T	E	N			T	O	B	R	E	T		A	N	D	C	H	E	T
I	N		T	H	E			M	O	R	N	I	N	G	T	H	E	Y	A	R	E
A		L	A	U	G	H		R	I	O	T										

Keep in mind that the Model 713 parsing utility can automatically perform this word-breaking function in encoder firmware. This illustration simply shows how parsing can be implemented manually. Additional discussion of dynamic PS modes and formatting may be found under advanced programming notes on Pages 49 through 52.

TEXT The 64-character RadioText buffer holds a static message that can be called up for viewing on home RDS receivers and on some auto radios. Please see further information on RadioText, Page 8.

The entire 64-character RadioText message is transmitted as a block. If so equipped, the *receiver* will buffer RadioText and display it as a scrolling message automatically, hence there is no need to observe word breaks or perform other message formatting tasks.

SPEED This refers *only* to COM port serial communications with the encoder, although the RS-232 rate may be set using the front-panel USB connection. See additional information on Page 21.

ECHO The Model 713 can be set either to echo RS-232 programming commands back to the computer or automation system, or not. The option is not important when using the supplied Windows® interface, but may have implication when addressing the encoder from a ‘dumb terminal’ or with station automation.

AF1 through AF9 Rebroadcast ‘translators’ or stations on a network may air the very same program on multiple frequencies. Only when the program is heard at the same time (synchronously) at different dial settings is the associated frequency considered a true “alternative frequency.”

NOTE: When AFs are listed, the station’s primary frequency *must* also be in the list. AF frequencies are selected from a drop-down menu associated with each AF button.

Sending Data to the Encoder Once all information is entered into the various fields, clicking the Send To Encoder button will upload all RDS data to non-volatile encoder memory. As data is received by the Model 713, the appropriate ACTIVE PORT indicator on the front panel will flash perceptibly.

Data transfer takes about 3 seconds, with progress indicated by a progress bar at the bottom of the window. Done. is displayed when transfer is complete, and if transfer is *not* successful for any of a number of reasons, an error message will be shown. The Done. message box must be cleared before further data can be entered.

Reading Data From the Encoder In a situation where the RS-232 data link is lost, once communication has been reestablished data may be read from the encoder to verify what is currently being broadcast. Clicking: Read From Encoder will copy all entries from the encoder buffer to the software screen.

The data resident in the Model 713 encoder memory may be downloaded back onto the software screen without interrupting RDS transmission. This feature is useful for updating only certain fields of RDS data being transmitted without having to re-enter everything. Download by clicking Read From Encoder, make changes in

any of the fields, and then upload the revised file back to the encoder with a Send To Encoder command.

File Management All the RDS programming information that is represented by the filled-in data entry screen may be also saved as a file on the computer hard drive. This is useful when various programming segments throughout the broadcast day have dedicated RDS messaging, or when messages need to be replaced within a programming segment with updated advertising or program promo information.

Data on the screen may be saved as a file before, after, or instead of sending information to the encoder. Clicking in the menu bar on: File / Save As... will prompt you for a location and name for the file, which will have a .ino extension. The file may be named in keeping with its content and stored on the computer Desktop, or in a folder created and set aside for this purpose. To import a saved .ino file onto the screen, click on File / Open and browse to the directory and folder where the .ino file has been saved. Double-click the file to bring the RDS programming information onto the screen where it then can be sent to the Model 713 encoder with: Send To Encoder.

PROGRAMMING PORT PRIORITIES

The RS-232 serial COM port is the default programming connection, but the front-panel USB port has priority over the COM and LAN ports. This allows local reprogramming of static data without disconnecting a station automation serial connection. The USB cable must be unplugged, or the local program closed, before the COM or LAN ports can again receive data.

ENCODER FRONT-PANEL INDICATORS

Five front-panel ENCODER STATUS indicators monitor Model 713 vital signs.

PWR. ON	This green LED glows whenever primary power is present. If this indicator is off, the encoder will have switched into the failsafe Bypass mode. In loop-through operation of the encoder, Bypass connects the PILOT OR MPX INPUT directly to the RDS OR MPX OUTPUT.
PILOT LOCK	This LED lights when the encoder has locked to the 19kHz stereo pilot signal from the stereo generator, either in the sidechain or the loop-through mode of encoder operation.
FREE RUN	When no 19kHz pilot is present at the PILOT OR MPX INPUT, the encoder defaults to a crystal-controlled internal timebase. This enables RDS transmissions with monaural programming. The FREE RUN LED shows that the encoder has defaulted to its internal timebase.

RDS
DATA

This LED flashes dimly as RDS data is being transmitted, serving as an indication that the encoder is operating normally. Even when no dynamic data is being sent, the various RDS groups of static identifiers are updated continually.

TA
FLAG

This LED flashes whenever the TA flag is raised, either with a software command or with a switch closure. **REMEMBER:** the TA flag is only temporary. It must be turned off as soon as the announcement ends.

Three more ACTIVE PORT indicators show which communications port is currently in use. The lighted indicator will flash perceptibly as data is passed to and from the encoder.

LAN

The LAN indicator lights only when the port is actually receiving data. On a network connection, the LAN indicator may go off even though the data-entry page remains on the computer screen. This is a normal network condition and should not be thought of as a loss of connection. With the next Send To Encoder or Read From Encoder command, the LAN indicator will once again show connectivity.

COM

The COM indicator is the default encoder port and lights whenever a USB or LAN connection is *not* active.

USB

This LED lights when the USB port is addressed.

In addition to the LED status indicators, the front panel also contains:

FUSE / DISCONNECT

The front-panel fuseholder also provides a means of disconnecting AC mains power in an emergency. Push the fuseholder cap down and pull it away from the panel to interrupt power.

INJECTION
LEVEL ADJUST

RDS injection level (subcarrier modulation) is set with this multiturn trim control. A detailed procedure for setting injection level can be found on Page 16.

Section V

TCP/IP CONNECTIVITY

The Model 713 Encoder includes an RJ-45 Ethernet port, which may be directly connected to a local network or to the Internet. An Internet browser may be directed to the encoder's IP address to bring up an encoder "Home Page" and a Web-based data-entry screen. This 'network' data-entry screen is under password protection and can be used to program the Model 713 registers in the same 'fill-in-the blanks' manner afforded by the Windows® software supplied with the encoder.

In addition, the encoder's IP address may receive raw ASCII data from station automation to permit dynamic messaging; for example, song title and artist. Programming syntax of this ASCII data is covered in Section VI, beginning on Page 41. The purpose of this section of the Manual is to guide the user through IP connectivity issues.

NOTE: It is energetically recommended that the Model 713 Encoder be set up for either USB or serial (COM port) communications before attempting to 'network' the encoder. These more basic means of communicating are foolproof, compared with the complexity of a network connection.

CONFIGURING THE LAN PORT

The encoder LAN port is a self-contained subassembly that incorporates all the networking functions and protocols. Each subassembly has an initial, individual DNS, which may be reassigned by the user. This LAN subassembly is by Lantronix Corp. and is called their XPort™. This is what gives the Model 713 its network connectivity. More information on this 'embedded device server' can be found on the Lantronix Website: <http://www.lantronix.com/device-networking/embedded-device-servers/xport.html>.

The XPort™ comes with a Lantronix software utility to help 'find' the Model 713, once it has been connected to the network. This software has been included on the Model 713 installation CD.

Support Software

With the Model 713 installation CD in the computer's CD drive, use Windows Explorer to navigate to the CD Drive (D:), right-click the drive and select: Explore to view the CD contents.


In addition to the two Model 713 software auto-install files, there are three folders of support software from other vendors. All contents of the CD are shown at the top of the next page.



Loading DeviceInstaller

Open the D:\Lantronix folder and double-click the file: lstarter.msi. If the computer you are using has seen much networking service, it well may have some version of the Microsoft “Dot-Net Framework” software already installed. If so, the Lantronix application will launch. Otherwise, you will see a notification window that the Microsoft application is required.

To install the Dot-Net Framework quickly and easily, click: No (do not go to the Internet) in the message box, and then open the D:\DotNetFX folder and double-click: dotnetfx.exe. When asked whether to proceed, as shown here, click Yes and follow the steps for installation.



With .NET Framework installed, reopen the Lantronix folder and double-click: Installer.msi to launch the DeviceInstaller Setup Wizard.

Unless you have reasons to the contrary, accept the default installation options. However, you might want to make the utility available for Everyone, rather than Just Me, which is one of the first options.

The Wizard does not place an icon on the Desktop, but when the


Connecting the Encoder to the Network

time comes the program may be launched from the Start menu.


The Model 713 must be configured for whatever network it is connected to. If it is ultimately to be accessed by the Internet, it first must be connected to local network for this configuration. If there is no local network, one can easily be simulated with an inexpensive router. These are commonly used to connect two or more computers to a single DSL or cable modem, and generally have one WAN port and 4 or more LAN ports. One of these routers may be found at popular computer emporiums for \$40 or less, and unless the router will provide the bridge to the Internet it is not necessary to run any software that comes with it. Simply connect the computer to one router LAN port and the Model 713 to the other.

With both the computer and the encoder connected to the network, launch the Lantronix utility: Start / All Programs / Lantronix / Device Installer, and then click: DeviceInstaller.

If more than one network is available to the computer, the box at right will appear. In this example, the checked network is the one connected to the Model 713, so OK may be clicked.




The DeviceInstaller screen will come up blank, as shown here. The software has a utility that searches for any Lantronix device. Click: Search to 'find' the Model 713.



Assigning the IP Address

DeviceInstaller will find the Model 713, but as the encoder has not yet been configured for this network, software will list the encoder as Unreachable, as indicated here. This means that the IP address needs to be set.



The utility will allow the network (our inexpensive router in this illustration) to assign the address automatically, but before clicking: OK to permit this, first *highlight* the xPort-03 line in the main box, and also write down the Hardware Address that shows on the screen. (One of the next screens may ask you to type in this address!) The address may always be found on a sticker attached to the Xport


module on the Model 713 circuit board, but it has conveniently been displayed for you here, as shown in the picture.

Click OK and then Assign IP. Type in the hardware address if you are asked for it, and accept the defaults to complete the IP Address assignment.


Confirming Device Properties

To avoid disappointment and frustration when addressing the encoder, take this opportunity to name the connection.

First, on the DeviceInstaller screen, click the encoder to highlight it, and then click Configure., as shown here.



A name to identify the encoder may be typed-in on this next screen. The name and any comments are associated with the particular encoder only within the DeviceInstaller software. The ID information is not uploaded to the Model 713. Naming the encoder is optional, but if there are multiple encoders on the network this will eliminate confusion when using DeviceInstaller to configure other units. A possible instance of this would be a group ownership situation, where several stations share facilities, including a common data network.



“BROWSER” NETWORK CONNECTION

With the encoder configured and connected to a network, addressing it can be as simple as typing the IP address of the encoder into a Web browser, such as Microsoft’s Internet Explorer. This will bring up the encoder’s own “Home Page,” shown here.



Java Installation

If the Home Page does *not* appear, you will probably get a message indicating that the computer does not have Sun Microsystems' Java infrastructure installed. We have provided this on the Model 713 installation CD, as shown at the top of Page 31. Open the Java folder and double-click: java.exe to install the needed routine.

Java Utility Implications

Web-based data entry is very convenient for the user, but this Java-based method of addressing the 713 carries a certain amount of 'overhead' that may slow or otherwise compromise communication, particularly over a busy private network or the public Internet where packets of data are frequently received out of sequence.

For this reason, we have provided a fallback communications utility that essentially provides a 'virtual COM port' for using the Model 713 Encoder software over any network with a great deal of 'robustness.' This alternative is detailed on Page 35.

Accessed through a browser, the encoder Home Page gives the user two choices. RDS System: Configure RDS System, is a system 'housekeeping' page. RDS Encoder: Configure RDS Encoder, directly addresses the Model 713. Click: Configure RDS Encoder to bring up the screen shown below.

Host 192.168.0.102 Rev. 1.0.0

Code PI FFFF Call RDS PTY None

PS INOV-713 PARSE 0 DPSS OFF DRTS OFF

MS MUSIC TA OFF TP OFF DI MONO

DPS ECHO ON

TEXT

AF1 NO AF AF2 NO AF AF3 NO AF

AF4 NO AF AF5 NO AF AF6 NO AF

AF7 NO AF AF8 NO AF AF9 NO AF

Read Write

[HOME]

1305 Fair Ave., Santa Cruz, CA 95060
TEL: (813) 458-0552, FAX: (813) 458-0554
www.inovon.com E-mail: info@inovon.com

This screen is almost identical to the one shown on Page 23. As data entry was covered in great detail under THE DATA ENTRY SCREEN, beginning on Page 22, it will not be repeated here. Please refer back to that discussion for instructions in filling-in the data-entry screen.


The primary utility of this screen is to set the static IDs and 'flags,' and to enter 'set-and-forget' scrolling-PS and RadioText messages. It does not afford the file management capability of USB and COM port connections using the specialized Windows[®] software provided with the Model 713.

Password Protection

The data-entry screen has a field for typing-in a password to protect the networked encoder from unauthorized access. The password is case sensitive and may use any combination of letters and numbers, as in the example shown here. Once this password has been uploaded to the Model 713, the screen's Write and Read buttons will not allow communication to and from the encoder, respectively, once password protection has been enabled.



Go back to the Home screen and click: Configure RDS System. This will open a box on the Configure screen where the password may be typed in. The upper Password box is for an existing password, if one had already been assigned. A new (or first) password is entered in the New Password box. Check the Enable Password box to allow the change, and the click the Update button to complete the operation.



This box also has a space to type in a New IP Address. The encoder IP and the Gateway of the network router may be entered here without having to use the Lantronix DeviceInstaller utility.

CREATING A 'VIRTUAL COM PORT'

As mentioned earlier, the Java utility necessary for an Internet browser interface may communicate very slowly or not prove completely reliable when encoder programming data is split into packets and transmitted out of sequence. The 'virtual COM port' method of addressing the encoder requires that the Model 713 Encoder software be resident, but this method ensures that the link between the computer and the encoder remains a fixed 2-way connection for the duration of data transmission.

Loading the Redirector Program

The virtual COM port is established using the Lantronix Redirector software supplied on the installation CD (see top of Page 31). Use Windows Explorer to open the Lantronix folder and double-click: RED32BIT.EXE.


This will initiate the Redirector installation Wizard shown on the right. Unless there are reasons to do otherwise, follow the installation instructions, which include shutting down and restarting the computer.




When the Redirector program is resident, start its Configuration utility with Start / All Programs / Lantronix Redirector / Configuration shown here.




This will bring up the RDCfg window for selecting one of the computer's COM ports for our purpose. For our example here we can choose COM4. As this will be a 'virtual' port, simply select a COM port that is *not* associated with a fixed application (internal modem or a hard-wired serial connector). Clicking: Com Setup will show a list of available ports. Ports that are 'grayed-out' will be permanent assignments of the computer.




Next, click: Add IP to bring up a second, IP Service Setup window. Type in the IP address of the encoder into the Host box. In the TCP Port box, enter 10001, which is the fixed TCP port assignment of the Model 713. With the assignments entered as shown, click: OK to close the IP Service Setup Window.



Back in the RDCfg window, click: Port Settings. Make sure that the Raw Mode box is checked. Click: OK, then Save, OK and Close.



When the Model 713 Encoder software is started, go to: COMM Port devices and make sure that COM4, the virtual port, is selected, with a baud rate of 9600, as shown here.



If the encoder has a network connection, it should only be necessary to click: Read From Encoder to bring up the contents of the registers.

NETWORK CONNECTION FOR AUTOMATION

Station automation may communicate easily with the Model 713 Encoder over a local network. Data-entry screens are of no use to station automation, thus programming commands and message syntax are detailed under Advanced Programming in Section VI.

Router Considerations

Network routers vary somewhat with regard to their setup for port settings, etc. In order for the Java routines imbedded in the Model 713 firmware to communicate properly, it may be necessary to reset port assignments within the networking configuration. The following information may be of use in this task.

The Network Data Entry screen, Configure RDS Encoder (shown on Page 34) uses Virtual Port 10001. The System Setup screen, Configure RDS System (shown on Page 35) uses Virtual Port 30718. Both these ports are IP ports and exchange data *packets*.

The TCP (*host exchange*) uses Virtual Port 80.

Section VI

ADVANCED PROGRAMMING FOR AUTOMATION

HARDWARE CONFIGURATION

Configuration of the terminal, computer or automation system obviously will depend on parameters placed by hardware and firmware. For simplicity, the encoder serial (COM port) and network IP programming illustrations in this section will utilize *HyperTerminal*, the terminal emulation program by Hillgraeve, Inc., developed for Microsoft and supplied with the Windows® operating system. It is hoped that programming instructions based on terminal emulation will help the programmer understand what ASCII syntax the encoder requires, serving as an example for direct-connection with station automation.

If using *HyperTerminal*, it's best first to upgrade to the latest version. Download this at no charge from www.hilgraeve.com/hpte. The more current product seems to run more smoothly and has text editing features not found in earlier versions.


NOTE: *Do not connect the Model 713 Encoder until the HyperTerminal program has been configured properly.*

HyperTerminal is started under Windows® with the command routine: Start / Programs / Accessories / Communications / HyperTerminal. Double-click: HyperTrm.exe. This brings up the main *HyperTerminal* screen with a Connection Description window for naming your encoder communications program. How this connection is configured depends on whether the serial (COM) port will be addressed, or if the encoder will use network (IP) connectivity




Serial COM Port Configuration

Give the encoder connection a name; we have chosen RDS for this illustration. Click Connect using and select COM1, unless there is a reason to use another serial COM port. Click OK.



The next window that appears shows COM1 Properties. Here you set the communications parameters as follows: Bits per second: 9600, Data bits: 8, Parity: None, Stop bits: 1, Flow control: None. Check your settings against the screen shot. Click OK to close all boxes and to clear the *HyperTerminal* data entry screen.




If you experience trouble communicating with the Model 713, there's a quick and easy check to verify that the computer and the terminal program are functioning normally. With pins 2 and 3 of the DB-9 connector shorted with a screwdriver, whatever is typed on the keyboard should appear on the screen.


When COM port setup is complete the computer may be connected to the encoder COM port. Next, skip to **Power-Up**, below.

Network Port Configuration

After starting *HyperTerminal*, name the encoder connection. For this illustration we have named this RDS via IP. Click: OK.

This will bring up the Connect To screen. Click: Connect Using and select TCP/IP (Winsock), as shown on the next page. This brings up a second Connect To screen.






On this second Connect To screen (above, right), type in the IP address for the Model 713 Encoder in the space marked Host Address:. Under Port number: type in: 10001. Then click: OK.

The computer should now be configured to communicate with the Model 713 over a local or other network.


Power-Up

Once the encoder is connected (by the serial COM or network LAN port) and powered-up, communications should be automatic. A notation at the bottom of the HyperTerminal screen verify connection.

Type: ??↵ (two question marks followed by Enter). This will cause the encoder to send back the contents of all ID, flag and message registers, which (shown here) are the data entered previously (Page 23). This double question mark can be used at any time to make the encoder ‘spill its guts.’ This exercise does not interrupt or interfere with encoder operation.



All valid interrogations are followed by: OK; a NO shows that the interrogation was not valid. Any *single* parameter in a register can be interrogated independently. Simply type the register designation followed by a single question mark. A response shown at the right for the typed command: PI?↵.



Echo

It's best for your computer screen to display what has been “echoed” by the encoder as data is entered. Each character typed on the keyboard is sent to the encoder, which turns it back around to be

shown on the monitor screen. This round trip gives continuous confirmation of 2-way communications. Typing ECHO=1↵ will provide this round-trip communications verification.

The return data path is not essential, however. The Model 713 will accept programming commands on a receive-only basis. For example, a studio-transmitter radio link (STL) may include 1-way data transmission that could be used to address the encoder.

If double characters appear when typing, your *terminal* has been configured for local echo. Rather than defeating the echo function of the encoder, local echo should be turned off. This is usually a software command in the terminal or terminal program. Local echo must be used with a 1-way link, however, so that the terminal screen will show what is typed.

The Model 713 has been set to echo as the factory default. The command to turn echo off is ECHO=0↵. To turn echo back on again, type ECHO=1↵.

PROGRAMMING SYNTAX

How to Type

In these programming instructions the *exact* ASCII syntax to be entered on the keyboard will be given in the font used in this example: DPS=HELLO↵. Specifically, the field: DPS, the equal sign and the word HELLO would be typed, followed immediately by pressing the Enter key. We will use ↵ as the symbol for Enter.

Take time to type deliberately and slowly. Even at 9600 baud, some delays are inherent in the communications between the computer and the encoder. One characteristic of typing too quickly will be the omission of line feeds in responses returned from the encoder.

Using ALL-CAPS

Programming commands should be typed in ALL CAPS (capital letters) and messages should be kept as simple as possible. Though the encoder will accept lowercase letters and all ASCII punctuation in the DPS and TEXT fields, RDS radio displays have limited character sets and may show ambiguous lowercase characters or gibberish. To assure readability, keep the keyboard Caps Lock key engaged and avoid fancy punctuation. ‘Smileys’ are not a good idea.


Correcting Mistakes

Under *HyperTerminal*, use the Enter key to drop to a new line, if required, and use either the Backspace key or the keyboard’s directional arrows to navigate within a text entry. Overtyping an entry will automatically replace the previous characters. What is shown on the screen before the Enter key is pressed is what will be sent to the encoder.

Validity Symbols

The Model 713 ignores ASCII inputs that do not conform to proper formatting rules. This is an important feature when the encoder is connected full-time to station automation. When a valid command is accepted by the encoder, it returns OK to the computer screen. If a data input is properly formatted, but is ambiguous or otherwise not accurate, the screen will display NO. Examples of valid and in-

valid commands are shown below. Follow programming instructions *exactly* to ensure that commands will be accepted.



ENCODER HOUSEKEEPING COMMANDS

Register Interrogation	Typing: ??↵ (two question marks followed by Enter) returns the status of all flag and ID settings and the contents of static message buffers to the screen. This was illustrated on Page 40.
Encoder Initialization	The “initialize” command is invoked by typing: INIT↵. This is used to reestablish encoder operation in the unlikely event of an internal software ‘crash,’ or for any other reason to restore all the factory defaults. INIT↵ is an emergency recovery command only. It is <i>not necessary</i> to execute INIT↵ prior to updating any encoder programming.
Saving Entries	Once the RDS parameters have been set-up, or after any updates have been made, type: SAVE↵ to write data to non-volatile memory. The SAVE↵ command may be executed at any time during the data entry process to protect everything entered to that point, and executed again when all entry is complete.
Encoder Reset	Typing: RESET↵ initiates a ‘hardware reset’ equivalent to turning the encoder off and back on again. This reset command does <i>not</i> clear the registers of programming commands that have been saved as described above.
Firmware Version	Type: REV↵ for a display of the encoder’s firmware version. This might prove important in determining whether differences exist between Model 713 encoders purchased at different times.

STATIC DATA PROGRAMMING

The following instructions describe the ‘hard way’ of programming the various IDs, flags, and static text messages. This programming is accomplished very easily using the Windows[®] data-entry software supplied with the encoder. Only the abbreviations of the functions are given. Refer to Pages 7 through 9 for in-depth parameter descriptions.

PI Calculation

In Europe and in some other parts of the world, an appropriate bureaucracy assigns the PI code for RDS transmissions. PI is a hexadecimal number that becomes the station ‘digital address.’ In the US the PI code is mathematically calculated from the station’s call letters using a formula published in the US RBDS Standard. This is a copious process, that’s why we built a calculator into the Windows[®] software supplied with the Model 713.

The manual PI calculation method shown here is valid only for four-letter calls. Three-letter calls have been preassigned. These are published in the RBDS Standard.

For the manual method, each letter of the alphabet is assigned a number value according to the following list:

A	0	H	7	O	14	V	21
B	1	I	8	P	15	W	22
C	2	J	9	Q	16	X	23
D	3	K	10	R	17	Y	24
E	4	L	11	S	18	Z	25
F	5	M	12	T	19		
G	6	N	13	U	20		


Now follow these simple(?) steps to calculate the PI. Here we have provided an example for Radio Station KWAV.

- 1) Take the number value of the *fourth letter* of your call and write it at the top of a column.
V=21 21
- 2) Take the number value of the *third letter* of your call, multiply it by 26 and add it to the column.
A=0 (X 26) 0
- 3) Take the number value of the *second letter* of your call, multiply it by 676 and add it to the column.
W=22 (X 676) 14872
- 4) If your call begins with a K, add 4096 to the column. If it begins with a W, add 21672.
K (add 4096) 4096
- 5) Add the column up. 18989


This gives a *decimal* number value for your call letters, which now has to be converted to *hexadecimal* for the PI entry.

The easiest way to convert from decimal to hexadecimal is with the Windows[®] accessory calculator. Bring the calculator up with the se-

quence: Start / Programs / Accessories / Calculator. Then select: View / Scientific and verify that the Dec (Decimal) box is checked. Enter your decimal sum with the keyboard keypad as shown below.



Next check the Hex box. The hexadecimal value will be displayed on the calculator as shown at the top of the next page.



The hexadecimal conversion shown in the example is 4A2D. This is an *alphanumeric* value containing both letters and numbers. Some PI codes may contain only numbers, but all will have four characters. Our four-character example is entered by typing: PI=4A2D↵.

PS The Program Service Name is your station's "Street Name." This may be simply the call letters, KBAD or KBAD-FM or a slogan such as LIVE 105. Up to 8 characters (including spaces) may be accommodated. Enter by typing: PS=xxxxxxxx↵, where x represents the entry in capital letters. (A discussion and instructions for scrolling-PS begin on Page 49.)

PTY "Program Type" indicates the station format. The listings shown below were assigned by the NRSC in the United States and by CENELEC for the rest of the world. *Be sure to select your format from the proper list!*

The numbers in the PTY column indicate the categories listed in the appropriate standards. Enter this number into the encoder's PTY field by typing: PTY=n↵ or PTY=nn↵, where n or nn is the number shown in the PTY column below.

<u>PTY</u>	<u>US (NRSC)</u>	<u>EUROPE (CENELEC)</u>
0	None	None
1	News	News
2	Information	Current Affairs
3	Sports	Information

4	Talk	Sports
5	Rock Music	Education
6	Classic Rock Music	Drama
7	Adult Hit Music	Culture
8	Soft Rock Music	Science
9	Top 40 Music	Varied
10	Country Music	Pop Music
11	Oldies Music	Rock Music
12	Soft Music	Easy Listening Music
13	Nostalgia Music	Light Classics Music
14	Jazz	Serious Classics Music
15	Classical Music	Other Music
16	Rhythm and Blues Music	Weather
17	Soft R and B Music	Finance
18	Foreign Language	Children's Programs
19	Religious Music	Social Affairs
20	Religious Talk	Religion
21	Personality	Phone-In
22	Public Non-Commercial	Travel
23	College	Leisure
24	(unassigned)	Jazz Music
25	(unassigned)	Country Music
26	(unassigned)	National Music
27	(unassigned)	Oldies Music
28	(unassigned)	Folk Music
29	Weather	Documentary
30	Emergency Test	Alarm Test
31	Emergency!	Alarm!

NOTE: PTY codes 30 and 31 are reserved for *true emergency and emergency test situations only*. Consult the appropriate Standards Group for using these PTY codes.

Also please take care in coding the PTY identifier, as the categories can be ambiguous. For instance, what if yours is a college station that relays NPR programming? How about Rock and Top 40 cross-overs? Just what can Cultural possibly pertain to in the 21st Century? Would Serious Classics dare to include Stravinsky or Bartok? For clarifications on these and other burning questions, refer to the appropriate RBDS or RDS Standard, or put your question directly to the Standards Group. Don't ask us, this is not in our job description!

The PTY identifier can be made into a semi-dynamic function. It can be changed from one entry to another if your station "dayparts" (alters formats during specific, extended periods). The PTY should *not* change from song to song or to accommodate a 5-minute newscast, however.

TP If yours is a station that transmits travel advisory updates on a regular basis, type: TP=1↵. If you do *not* broadcast travel information, type: TP=0↵.

TA The Travel Announcement flag can be software-activated by typing: TA=1↵, but *must* be turned off by typing TA=0↵ *immediately* when the announcement ends. TA is most easily and safely activated with a hard-wired switch closure at the announcer's position (see Page 14). Leave the software command set at TA=0↵ and use the switch!

TA Timeout An optional safety feature has been built into the Model 713 to guard against an extended software-activated TA flag. Say, for example, that the TA flag was activated by the software command: TA=1↵, and the data link was suddenly lost. No TA=0↵ command would be received, and the TA flag would remain raised indefinitely. As this is not a good thing, an automatic timeout option has been included for *software-activated* TA flags.

Timeout can be set between 1 and 9 minutes. To enable this feature, type: TATIME=m↵, with the value of m between 1 and 9. This will automatically reset the TA flag to TA=0 after the programmed time has elapsed.

As received, this timeout feature is disabled. Type: TATIME?↵. A zero returned from the encoder shows that the feature is turned off. The feature is disabled by typing: TATIME=0↵.

NOTE: The timeout should not be used to define the actual period that the TA flag is raised. The TA flag *must* be reset to zero immediately following a traffic announcement. Again, it's best to use the manual switch option for this command as described on Page 14.

AF As many as 9 Alternative Frequencies may be entered in to the Model 713. These are optional frequencies that carry the *very same* program as the main channel, as in a network or translator situation.

Alternative frequencies are actually transmitted as special AF *channel numbers*. The RDS receiver logs these channel values and uses them in the process of finding a stronger signal of the identical program, either from another station on a network or from a rebroadcast translator.

The Model 713 has nine registers for alternative frequencies. Each register must have a numerical value assigned and entered into it. Any register that is *not* used for an alternative frequency must have a 0 (zero) value inserted. The factory default is a zero in all registers.

Alternative frequency channels begin with Channel 1 at 87.6MHz, and go in 100kHz increments up to Channel 204 at 107.9MHz. The following table converts frequency to AF channel numbers.

<u>MHz</u>	<u>CHAN</u>	<u>MHz</u>	<u>CHAN</u>	<u>MHz</u>	<u>CHAN</u>	<u>MHz</u>	<u>CHAN</u>
87.6	1	92.7	52	97.8	103	102.9	154
87.7	2	92.8	53	97.9	104	103.0	155
87.8	3	93.9	54	98.0	105	103.1	156
87.9	4	93.0	55	98.1	106	103.2	157
88.0	5	93.1	56	98.2	107	103.3	158

88.1	6	93.2	57	98.3	108	103.4	159
88.2	7	93.3	58	98.4	109	103.5	160
88.3	8	93.4	59	98.5	110	103.6	161
88.4	9	93.5	60	98.6	111	103.7	162
88.5	10	93.6	61	98.7	112	103.8	163
88.6	11	93.7	62	98.8	113	103.9	164
88.7	12	93.8	63	98.9	114	104.0	165
88.8	13	93.9	64	99.0	115	104.1	166
88.9	14	94.0	65	99.1	116	104.2	167
89.0	15	94.1	66	99.2	117	104.3	168
89.1	16	94.2	67	99.3	118	104.4	169
89.2	17	94.3	68	99.4	119	104.5	170
89.3	18	94.4	69	99.5	120	104.6	171
89.4	19	94.5	70	99.6	121	104.7	172
89.5	20	94.6	71	99.7	122	104.8	173
89.6	21	94.7	72	99.8	123	104.9	174
89.7	22	94.8	73	99.9	124	105.0	175
89.8	23	94.9	74	100.0	125	105.1	176
89.9	24	95.0	75	100.1	126	105.2	177
90.0	25	95.1	76	100.2	127	105.3	178
90.1	26	95.2	77	100.3	128	105.4	179
90.2	27	95.3	78	100.4	129	105.5	180
90.3	28	95.4	79	100.5	130	105.6	181
90.4	29	95.5	80	100.6	131	105.7	182
90.5	30	95.6	81	100.7	132	105.8	183
90.6	31	95.7	82	100.8	133	105.9	184
90.7	32	95.8	83	100.9	134	106.0	185
90.8	33	95.9	84	101.0	135	106.1	186
90.9	34	96.0	85	101.1	136	106.2	187
91.0	35	96.1	86	101.2	137	106.3	188
91.1	36	96.2	87	101.3	138	106.4	189
91.2	37	96.3	88	101.4	139	106.5	190
91.3	38	96.4	89	101.5	140	106.6	191
91.4	39	96.5	90	101.6	141	106.7	192
91.5	40	96.6	91	101.7	142	106.8	193
91.6	41	96.7	92	101.8	143	106.9	194
91.7	42	96.8	93	101.9	144	107.0	195
91.8	43	96.9	94	102.0	145	107.1	196
91.9	44	97.0	95	102.1	146	107.2	197
92.0	45	97.1	96	102.2	147	107.3	198
92.1	46	97.2	97	102.3	148	107.4	199
92.2	47	97.3	98	102.4	149	107.5	200
92.3	48	97.4	99	102.5	150	107.6	201
92.4	49	97.5	100	102.6	151	107.7	202
92.5	50	97.6	101	102.7	152	107.8	203
92.6	51	97.7	102	102.8	153	107.9	204

To enter the alternative frequency of 98.1MHz into register one, type: AF1=106↵. To enter the alternative frequency of 107.7MHz into register two, type: AF2=202↵. Enter a value into all nine registers. If only a couple of alternative frequencies are entered be sure

that a 0 (zero) is typed into any unused registers. Typing: ??↵ will confirm the contents of the nine AF registers.

NOTE: The alternative frequency utility requires that the station's *main frequency* be entered into one of the registers, whether that station has translators or not. Be sure to enter the primary frequency of the station into one of the registers, and that zeroes are in unused registers.

- DI** Though this identifier is not presently used to any great extent, to be on the safe side type: DI=1↵ if you are a *stereo* station, and type: DI=0↵ if you broadcast only in monaural.
- M/S** The utility of this flag also is obscure. Nevertheless, it is recommended to type: MS=0↵ if your broadcast day is primarily speech, such as All-News or Talk Radio, and type: MS=1↵ if music makes up the bulk of your programming.
- RT** RadioText is the static message that appears on the faceplate when the listener presses and INFO button, on radios so equipped. This is not to be confused with the PS field, which can be either static or dynamic. Some stations make RadioText a dynamic function, changing the message at intervals to promote an upcoming broadcast, to announce results of a contest, or to send advertising messages. We recommend that you program a default RadioText message into static memory and initiate a SAVE↵ command. This will ensure that the RadioText field will not be empty following a power outage or loss of the data link.

To enter the static RadioText type: TEXT=x₁x₂x₃ . . . x₆₄↵, with x representing up to 64 *uppercase* characters, including spaces; a RadioText message may be shorter than 64 characters, however.

Even with a default message saved in non-volatile memory, RadioText is updated simply by entering new data. This may be done manually from a computer or terminal, or automatically by station automation for messages that change during the day. When connecting the encoder's RS-232 COM PORT to the automation system, be sure that the system is configured for the proper data rate and programmed to give the TEXT=... header when sending data.

RadioText Rate Generally, RadioText is updated less frequently than IDs and flags to speed the radio's search for formats, traffic information and alternative frequencies. The tradeoff is that text messages are sent and updated less frequently. There will always be a tradeoff between RadioText throughput and speed of other RDS functions, including AF-seek and either static or scrolling-PS displays.

The RadioText update rate is programmed by typing: DRTS=n↵, with n a number between 1 and 9, corresponding to a refresh rate between slow and fast, respectively. Keeping the throughput tradeoff in mind, unless RadioText is being used for contests or for other quasi-dynamic activities, it is best to use a lower number. A rate of 1, 2 or 3 will make little difference in the speed of other RDS functions.

NOTE: RadioText can be turned off entirely by typing: DRTS=0↵. A zero value in this field turns the RadioText message off, but does not delete any saved message from memory.

Free Format Group

The encoder can transmit two unspecified data groups for in-house remote control, restricted paging or similar proprietary applications. This feature can be static, with the same data transmitted repeatedly, or controlled by an external application as a dynamic function.

The two “free data” groups are known as the ‘G’ and ‘H’ groups. Each contains three hexadecimal ASCII blocks of data. To enter data into these groups, type: **G=bbbbccccdddd**↵ and/or: **H=bbbbccccdddd**↵. The blocks represented by bbbb, cccc and dddd are the RDS B, C and D data blocks. Certain hexadecimal values in these blocks may already be in use for RDS functions supported by the 713 encoder. Consult the applicable RBDS or RDS Standard for more information on how these data can be used.

Saving Entries

Once all data have been entered, execute a **SAVE**↵ command to write your entries to non-volatile memory. Data held in non-volatile memory is loaded into working memory following a power-up or a **RESET**↵ command. Saving to non-volatile memory is a precautionary measure and does not limit dynamic operation.

SCROLLING DISPLAYS AND DYNAMIC ENCODER OPERATION

Safety Considerations

The concept of scrolling text messages on the dashboard of a car, in plain view of the driver, is the subject of discussion and debate within the broadcast community and with transportation safety agencies. It should be a matter of common-sense concern to the responsible broadcaster as well.

Inovonics takes a cautionary, conservative view of dynamic message displays in plain view of an automobile driver. The CENELEC and NRSC standards groups have expressly forbidden this practice for good reason. Proponents argue that GPS and other navigational aids in cars pose a similar and equal hazard, even though these displays are often more of a ‘heads-up’ display than the faceplate of a dash-mounted radio. Indeed, propping a paperback mystery novel on the car’s steering wheel is more ‘heads-up’ than the radio faceplate, but do these scrolling display proponents condone reading while driving, we wonder? It is our recommendation to relegate visual readouts to display only essential information, and in a manner that poses the least distraction.

RadioText

RadioText is transmitted as a 64-character block of data. The presentation of this display has been left to receiver manufacturers. Some home receivers can actually show the entire message at once, whereas other radios must scroll the message in a limited window. A good number of auto radios simply do not support Radiotext, and others require the operator to press an INFO button to display text. A few car radios disable the RT readout when the car is moving.

Dynamic PS When the CENELEC and NRSC standards for RDS/RBDS were initially drafted, scrolling text in the PS field was specifically forbidden. Despite this edict, not to mention the inferences of common sense, the refresh rate of the PS field makes message scrolling not only possible but also tempting. Early implementers of RDS discovered the means by which this could be done, and encoder manufacturers rose to the occasion with accommodating hardware. Now third-party ‘data consolidators’ provide message formatting services on a subscription basis to broadcasters, fitting messages into the 8-character PS field by calling on Internet connections and links to libraries of song titles, weather forecasts, stock quotes and sponsor’s advertisements.

‘Block’ Transmission The quickest and most popular PS messaging format is block transmission, which is supported and simplified by the Model 713 ‘parsing’ utility (see Page 24). Rather than scrolling the message across the receiver faceplate like so many marching soldiers, the message is formatted into 8-character blocks of text. Song title and artist information is sent on sequential 8-character screens like this:

```

F I R S T   C U T   I S   T H E
D E E P E S T   S H E R Y L   C R O W

```

This gives the information in six screens. With a typical refresh rate of two seconds per screen, this same information could be repeated several times during the song, and even interspersed with a preview of the next selection, advertising, or a station ID and promo.

A message in the block format must be watched almost continuously to avoid missing part of the text. If the message can be counted on to repeat, a missed portion could be caught next time around. But if a lot of information is flying along at a good clip, the data-deprived driver could easily be distracted.

“Safe Scrolling” In the interest of safety, Inovonics developed an alternative technique that more closely fits the description of scrolling-PS, very much like soldiers marching past a reviewing stand. This alternative is not nearly as fast as the block transmission method, but is far safer. Here is how the same song and title would look:

```

F I R S T   C   F I R S T   C U   I R S T   C U T
R S T   C U T   S T   C U T   I   T   C U T   I S
C U T   I S   C U T   I S   T   U T   I S   T H
T   I S   T H E   I S   T H E   I S   T H E   D
S   T H E   D E   T H E   D E E   T H E   D E E P
H E   D E E P E   E   D E E P E S   D E E P E S T
D E E P E S T   E E P E S T   C   E P E S T   C H
P E S T   C H E   E S T   C H E R   S T   S H E R Y

```


Using the automatic parsing utility (PARSE=0), text is entered without need for special formatting, perhaps just as it comes from station automation.

There is sufficient space available to add further information such as *ON KWARV* or *REM RECORDS*. If no text is entered in the blank, trailing fields, the message will begin repeating from the beginning once the display clears by scrolling completely off-screen.

DON'T FORGET that all the static RDS registers, including simple scrolling messages, can be entered or changed easily through either the Windows[®] or network data entry screens.

Section VI

APPENDIX

TABULATED LISTING OF ENCODER COMMANDS AND PROMPTS

PARAMETER	COMMAND	DATA ENTRY
Program Identification	PI=	4 digit HEX number (station “digital address”)
Program Service Name	PS=	8 (max) ASCII characters (station “street name”)
Dynamic PS	DPS=	64 (max) ASCII characters (for messaging in PS field)
Dynamic PS Speed	DPSS=	0 to 9 (0 = Off, 1 = slow, 9 = fastest)
Dynamic PS Method	PARSE=	0 through 9 (0 = parsed, centered; 1-8 Safe Scrolling; 9 = parsed, left-justified)
Program Type	PTY=	1 or 2 digit number (describes station format)
Traffic Program	TP=	0 or 1 (0 = no, 1 = yes)
Traffic Alert	TA=	0 or 1 (0 = flag off, 1 = flag on)
Software TA Timeout	TATIME=	0 to 9 (0 = function off, 1-9 = minutes to timeout)
Alternative Frequencies	AF1=	0 to 204 (0 = blank; 1 to 204 = “channel” in 100kHz increments, 87.6MHz to 107.9MHz)
	AF2=	
	AF3=	
	AF4=	
	AF5=	
	AF6=	
	AF7=	
	AF8=	
	AF9=	
Decoder Information	DI=	1 digit HEX number (defines mono or 2-channel mode)
M/S	MS=	0 or 1 (0 = speech-only, 1 = music)
RadioText	TEXT=	64 (max) ASCII characters
Dynamic RadioText Speed	DRTS=	0 to 9 (0 = Radiotext off; 1 to 9 = update rate, slow to fast)
RS-232 Serial Baud Rate	SPEED=	2400 or 4800 or 9600 or 19200 or 39400 or 57600 or 15200 baud
Command Echo	ECHO=	0 or 1 (0 = echo off, 1 = echo on)

	COMMAND	SPECIAL COMMANDS
	?	Followed by command without equal sign returns status of encoder memory for that parameter; e.g.: AF3?.
	??	Returns all data in encoder memory.
	REV	Returns firmware revision number.
	SAVE	Saves all uploaded commands to non-volatile RAM.
	RESET	Resets the encoder as if AC power were cycled off and on.
	INIT	Initializes the encoder to all factory defaults.
RESPONSE	MEANING	
OK	Command received by encoder properly formatted and understood.	
NO	Command properly formatted but data not understood.	
(NONE)	Data sent is ignored by the Model 713.	



INOVONICS WARRANTY

- I **TERMS OF SALE:** Inovonics products are sold with an understanding of “full satisfaction”; that is, full credit or refund will be issued for products sold as new if returned to the point of purchase within 30 days following their receipt, provided that they are returned complete and in an “as received” condition.
- II **CONDITIONS OF WARRANTY:** The following terms apply unless amended *in writing* by Inovonics, Inc.
 - A. The Warranty Registration Card supplied with this product *must* be completed and returned to Inovonics within 10 days of delivery.
 - B. This Warranty applies only to products sold “as new.” It is extended only to the original end-user and may not be transferred or assigned without prior written approval by Inovonics.
 - C. This Warranty does not apply to damage caused by misuse, abuse, accident or neglect. This Warranty is voided by unauthorized attempts at repair or modification, or if the serial identification label has been removed or altered.
- III **TERMS OF WARRANTY:** Inovonics, Inc. products are warranted to be free from defects in materials and workmanship.
 - A. Any discrepancies noted within ONE YEAR of the date of delivery will be repaired free of charge, or the equipment will be replaced with a new or remanufactured product at Inovonics’ option.
 - B. Parts and labor for factory repair required after the one-year Warranty period will be billed at prevailing prices and rates.
- IV **RETURNING GOODS FOR FACTORY REPAIR:**
 - A. Equipment will not be accepted for Warranty or other repair without a Return Authorization (RA) number issued by Inovonics prior to its return. An RA number may be obtained by calling the factory. The number should be prominently marked on the outside of the shipping carton.
 - B. Equipment must be shipped prepaid to Inovonics. Shipping charges will be reimbursed for valid Warranty claims. Damage sustained as a result of improper packing for return to the factory is not covered under terms of the Warranty and may occasion additional charges.